



NCFI CERTIFIED INSULATION CONTRACTOR PROGRAM REQUIREMENTS FOR CERTIFICATION

GoldStar certified applicators will be represented to the public by NCFI as having demonstrated competence with the application of spray polyurethane foam insulation, troubleshooting of spray polyurethane foam application equipment, experience, knowledge of insulation characteristics and building codes, and financial stability.

To be considered an NCFI GoldStar Certified Applicator, you will need to meet the following requirements.

Requirements:

1. Equipment Training/Knowledge:
 - a. Contractor has attended NCFI Advanced Equipment School or has demonstrated to NCFI's satisfaction that they have acquired sufficient knowledge to safely operate, maintain, and troubleshoot spray foam equipment.
 - b. Contractor has reviewed NCFI's Product Stewardship Manual and returned its signature confirmation form.
 - c. Contractor has completed the American Chemistry Council (ACC)'s Center for the Polyurethanes Industry (CPI)'s [High Pressure SPF Chemical Health and Safety Training](#). Provide System ID Number upon completion.
2. Experience: Contractor must have applied at least 50,000 lb. of insulation spray foam within the last five years with demonstrated proficiency.
3. Purchase History: Contractor must have purchased at least 25,000 lb. of insulation foam chemicals per year.
4. Financial Stability: Contractor must demonstrate financial stability. Criteria may include credit history, audited financial statements, etc.
5. Insurance: Contractor must maintain a minimum of \$1 million of business liability insurance and provide a copy of their liability insurance certificate.
6. Insulation Knowledge: Contractor must pass an NCFI administered insulation knowledge test to demonstrate they have a minimal understanding of spray foam insulation systems.